

Ademco 4140 XMPT / First Alert 1300

Zones - 9 Hardwired, up to 64 total zones with wireless

Wireless - Yes

Batteries Main Panel 12 volt rechargeable Gel-Cell inside main panel
AC Transformer is 16.5 Volts

Doors/ Windows/Motions 3-volt Lithium (Panasonic CR123A)

Smoke Detector 2 9-volt Alkalines

Keyfobs and Panics 2 3-volt Lithium (CR2025 Hearing Aid type)

Note: some keyfobs and panics use CR2430 Lithium

Panic Buttons Police Panic - * and #

Fire Panic - 1 and *

Medical Panic - 3 and #

Status - Press * if keypad shows NOT READY to view open zones

Arm Away - 4-digit code + 2 (AWAY) to arm everything

Arm Stay - 4-digit code + 3 (STAY) to arm everything but motions

Quick-Arm (If Enabled) # + 2 for AWAY, # + 3 for STAY

Instant Arm - 4-digit code + 7 (INSTANT), also bypasses motions

Max Arming - 4-digit code + 4 (MAX), arms everything including motions
instant

Disarm - 4-digit code + 1 (OFF)

Silence Alarm - 4-digit code + 1 (OFF) twice to turn off siren and reset display

Bypass - 4-digit code + 6 (BYPASS) + Zone (01, 02 03 etc)
(Keypad will beep and BYPASS + Zone will show on display)

Door Chimes - 4-digit code + 9 (CHIME)

Reset Smoke - 4-digit code + 1 (OFF) twice to turn off siren and reset smoke (If this does NOT reset smoke detector set for service, smoke is bad)

Alarm Memory 1. Enter 4-digit code + # + 6 + 0, select 0 for Recent or 1 for Complete log

2. Select Partition (press 0 for all partitions)

3. Press 1 for previous log entries or 3 for next log

entries

4. Press 8 to select category and 8 again for next entry

5. Press * to exit

Test Sensors - 4-Digit Code + 5 (TEST)

Keypad will beep every 3 minutes

Open sensors and keypad will sound

End test with 4-digit Code + 1 (OFF) key

(Wireless motions require no movement for 4 minutes prior to testing)

Setting Clock - 4-digit code + #63

6 moves from Hour to Minute to Month to Date to Year

4 moves backwards

Press 3 or 1 to change values

Press 8 to save and exit, press * to exit without saving